

BlackVue Cloud Viewer – Interface Guide

Account and Info

- About BlackVue Cloud Viewer
- Adjust language, file location, map speed unit, map service

• Create an account, check usage, change password, logout

• Access help, terms of use, latest news from BlackVue, all notifications

• Click to start or end Live View

• Switch between your dashcam's location and the publicly shared cameras map

• Double-click a camera to start Live View.

• Right-click a camera to modify camera settings, view camera info, change camera name or unregister a camera.

• Register a BlackVue dashcam to your account

• Select to view files in the BlackVue, Cloud Storage, or Local Disk.

* Click '...' to change the Local Disk file storage location.

• Filter files by direction and recording mode:

- Front
- Rear
- Normal
- Event
- Parking
- Manual

Playback Screen

- Click to turn on/off the voice communication feature.
- Map screen
- View full screen
- Flip upside-down
- Flip horizontally
- Fit to playback screen

Recorded file list

- Double-click a file to play.
- Right-click a file to copy to local disk or copy to the cloud.

Map Screen

- Your BlackVue account
- Click x to close the current file and return to the map

Camera settings

Right-click on your camera in **My camera(s)** and select **Camera settings** to open the settings window.

